

PG300

Digital Pressure Gauge Operating Instructions

Operating/Mounting Instructions

1. Mount the gauge on a suitable (or appropriately sized) NPT female fitting. Use Teflon Tape or Pipe Dope. Do not over tighten.
2. Depress ON/OFF button to power up unit (no pressure applied). If there is a reading other than zero, press the ZERO RESET button to zero-out the display. Press the On/Off button to switch to the desired pressure scale.
3. Apply pressure to the gauge - the display should now indicate the pressure being applied.
Note: If the Zero Button is pressed when the pressure is changing, the display will not indicate "0" (no pressure applied). Press the ZERO button to Zero-out the display once the pressure has been stabilized
4. Press the ON/OFF button to shut off display. Note: The display will automatically turn off after approximately 3 minutes
5. Battery Replacement: The battery is located within the inside of the rear cover. Remove the screw to remove the rear cover. Using a small screwdriver to slide the battery out un-snap the old 9V battery and replace with the new battery. Replace the rear cover and the screw when complete.



Global Water
The Leader in Water Instrumentation

In the U.S. call toll free
at 1-800-876-1172
International: 916-638-3429
Fax: 916-638-3270
Email: globalw@globalw.com

Visit our online catalog at:
www.globalw.com
Our Address:
11390 Amalgam Way
Gold River, CA 95670