



**Global Water**  
Instrumentation, Inc.

**Addendum: Communication Commands for Windows Datalogger**

The following is a chart of commands that can be sent to the Windows Datalogger through a terminal program.

<b>Command</b>	<b>Description</b>
D	Set Date
T	Set Time
?	Get number of data points
h	Get first historical data point
a	Get historical data point again
X	Abort
i	Get next historical data point (increment)
E	Erase
r	Get real time data point
!	Set description
1	Get description
@	Set Units
2	Get Units
#	Set Raw Scale
3	Get Raw Scale
\$	Set Engineering Unit Scale (EU)
4	Get Engineering Unit Scale (EU)
N	Set Name
n	Get Name
S	Set Sample interval
s	Get Sample interval