



SIT60 Satellite Internet Telemetry



- Remote Data and Control Anywhere, Guaranteed!
- Data by Internet to your computer
- Real time spread sheet data with control
- Alarms by text to your cell phone
- Interface to almost any sensor
- Easy installation—just install antenna and turn it on.
- Low cost/Economical
- Solar/Battery or AC power
- Security monitoring and alarms

Description

Global Water's new SIT-60 Satellite Internet Telemetry provides the easiest and most reliable way to collect remote environmental data. The SIT-60 uses the latest satellite and Internet technologies to bring data to your computer in near real time. Any Global Water sensor and almost any other sensor may be interfaced to the SIT-60. Four analog inputs, 2 status/accumulator inputs are standard, with optional 8 analog 4 digital and 2 control outputs. Just hook up your sensors, point the antenna to the sky and turn on the SIT-60. Satellite service is available anywhere in the world. Data is transmitted at a timed programmable and/or alarm basis and transferred via satellite and Internet to your dedicated web page. You can monitor and collect data anywhere you have web access.

Specifications

Inputs: 4 analog (8 optional) 0-5Vdc or 4-20mA

1 digital (4 optional) contact closure

Outputs: Optional 2 digital contact closure

Operating Modes: Timed, Event and Analog Event

Power Requirements: 12 VDC

Current Draw: 5 mA standby

2A transmitting

Temperature: -40° to +60°C

Humidity: 0 to 100% non-condensing

Price List

SIT60

Satellite Internet Telemetry..... \$1570

Subscription service.....\$Varies depending on number of sensors and transmission interval

4 Extra analog inputs.....\$795

1 Digital input (up to 4.).....\$72

1 Digital output (up to 4).....\$72

AC Trickle Charger Option.....\$18

Smart Charger.....\$105

SP102 Solar Panel (5 watts, 300mA min)...\$325

(Two SP102s per system recommended for non-AC systems)

Contact
Global Water
for all your
instrumentation
needs:

Water Level

Water Flow

Water Samplers

Water Quality

Weather

Remote Monitoring

Control



Global Water
The Leader in Water Instrumentation

In the U.S. call toll free

at 1-800-876-1172

International: 916-638-3429

Fax: 916-638-3270

Email: globalw@globalw.com

Visit our online catalog at:

www.globalw.com

Our Address:

11390 Amalgam Way

Gold River, CA 95670