

DPD Powder Pop®

Portable Dispenser for Chlorine Testing



Description

The DPD Powder Pop® is a handy portable dispenser that accurately delivers the correct volume of DPD reagent for free or total chlorine testing. The dispenser contains enough DPD powder for 100 tests, or you can purchase multi-packs for high volume testing. To use, simply invert the dispenser over the sample and press the button to dispense the reagent. The powder dissolves quickly in the sample, leaving no messy residue behind. The unit is available for 5 ml and 10 ml sample sizes with formulations that work with HF Scientific and a variety of other manufacturer's test kits.

Features

- Compact, convenient and disposable
- Simple push button operation allows for precise dosing
- No spill dispensing into most round or square cuvettes
- Non-clog design works every time

Ordering & Options

Order No.	Test Description and Formulation
10500	PPD-2 DPD - 5ml Sample x 100 Tests for Free Chlorine
10500C	PPD-2 DPD - 5ml Sample x 1000 Tests ¹ for Free Chlorine
10502	PPD-2 DPD - 5ml Sample x 100 Tests for Total Chlorine
10502C	PPD-2 DPD - 5ml Sample x 1000 Tests ¹ for Total Chlorine
10504	PPD-2 DPD - 10ml Sample x 100 Tests for Free Chlorine
10504C	PPD-2 DPD - 10ml Sample x 1000 Tests ¹ for Free Chlorine
10506	PPD-2 DPD - 10ml Sample x 100 Tests for Total Chlorine
10506C	PPD-2 DPD - 10ml Sample x 1000 Tests ¹ for Total Chlorine
10504T	PPD-2 DPD Tablets ² - 10ml Sample x 100 Tests for Free Chlorine
10506T	PPD-2 DPD Tablets ² - 10ml Sample x 100 Tests for Total Chlorine

1) 5 x 200 tests

2) For test kits using tablet technology



Global Water
The Leader in Water Instrumentation

In the U.S. call toll free
at 1-800-876-1172
International: 916-638-3429
Fax: 916-638-3270
Email: globalw@globalw.com

Visit our online catalog at:
www.globalw.com
Our Address:
11390 Amalgam Way
Gold River, CA 95670