

PH-25 pH Tester



- Advanced technology
- Handy pocket size
- Automatic calibration
- Waterproof housing
- Built-in BNC connector for use with standard lab electrodes

Description

The Pinnacle Chek-Mite pH-25 pH Testers provide a whole new level of performance in an inexpensive line of pocket pH testing instrumentation. Featuring advanced microprocessor technology, Chek-Mite pH Testers offer automatic calibration (to values of 4, 7, or 10.01). Sealed components and casing are waterproof, and enable the testers to float when dropped in water. The pH-25 pH Testers offer a BNC electrode connector which allows several different pH tester electrode options. The testers also provide pH measurement with automatic calibration and auto or manual sample end-point determination. This line of pH Testers comes with a six-month warranty.

Specifications

Range: 0-14 pH
Resolution: 0.01
Accuracy: ±0.04 pH
Temperature Compensation: Set @ 77 F (25 C)
Calibration: Auto
of Calibration Points: 2 of 3
ISO Potential Point: 7 pH
Sensor Type: BNC connector
Battery Life: >100 hrs. (Based upon Intermittent Daily Usage)
 Batteries are replaceable
Auto OFF: After 8 minutes, if no key is pressed
IP Rating: IP-66+ (Waterproof to depth of 2 inches (50 mm))
Certifications: CE Directives EN-55011 & EN-50082-1
Warranty: 6 months
Size: 9.0x1.75x1.25 inches (230x44x30 mm) (H x W x D)
Weight: Approximately 5 oz (115 g)

Price List

pH-25 pH Tester

pH tester electrode not included.....	\$77.56
476326	
General Purpose Electrode.....	\$142.33
476286	
Flat surface electrode.....	\$259.31
476086	
Refillable General Purpose Electrode.....	\$187.54

Contact
 Global Water
 for all your
 instrumentation
 needs:

Water Level

Water Flow

Water Samplers

Water Quality

Weather

Remote Monitoring

Control



Global Water
 The Leader in Water Instrumentation

In the U.S. call toll free
 at 1-800-876-1172
 International: 916-638-3429
 Fax: 916-638-3270
 Email: globalw@globalw.com

Visit our online catalog at:
www.globalw.com
 Our Address:
 11390 Amalgam Way
 Gold River, CA 95670