

BLR-Series Disposable Bailers

Polyethylene Bailer for Groundwater Sampling



Description

The BLR-Series single use disposable bailers help eliminate the common storage and cross contamination problems associated with conventional bailers. The BLR's design allows the bailers to fill 33% faster than conventional units. The bailers feature a V-notch top for easy cord attachment and pouring, a retained check ball valve for easier sampling, and welded seams for extra strength. The BLR units are certified clean through independent laboratory testing and analysis on each material lot. Weighted bailers have a completely encapsulated weight so no metal comes in contact with the sample. The double check valve bailer isolates the sample, sealing it as the bailer is removed from the well at specific depths.

Pressurized Disposable Bailers

The special pressurized bailer provides the convenience of using inline dispos-a-filters™ in the field even when pumps are not available. By using a pneumatic hand pump, you can filter your samples directly from the disposable bailer, saving time while maintaining sample integrity. Pressurized bailers come complete with barbed hose adapters for attaching the hand pump to the top of the bailer, as well as special adapters with a notched thread to be used with a dispos-a-filter™ at the bottom. In order to displace the check ball and establish a smooth flow, an additional large barbed removal device is included for bottom emptying without filtering.

Features

- Fills 33% faster than other bailers
- Trouble-free cord attachment and accurate pouring
- Manufactured under strict clean room conditions
- Highest quality, virgin materials

Ordering & Options

Disposable Bailers

Order No.	Diameter	Length	Configuration	Units/Case
CVA000	3/4"	36"	Non-Weighted	24
CVA010	1-1/2"	12"	Non-Weighted	24
CVA020	1-1/2"	36"	Non-Weighted	24
CVA030	1-1/2"	48"	Non-Weighted	24
CVB000	3/4"	36"	Weighted	24
CVB010	1-1/2"	12"	Weighted	24
CVB020	1-1/2"	36"	Weighted	24
CVB030	1-1/2"	48"	Weighted	24
CVB040	1-1/2"	83"	Weighted	12
CVB050	3"	36"	Weighted	9
CVC000	1-1/2"	36"	Double Check	24
CVD000	1-1/2"	36"	Pressurized	12

Accessories

Order No.	Description	Units/Case
CVEA00	Poly VOC Tips for 3/4" Diameter Bailers	24
CVEA10	Poly VOC Tips for 1-1/2" Diameter Bailers	24
CVEA20	Poly VOC Tips for 3" Diameter Bailers	9
CVEB00	Product Samplers (for free product sampling)	24
CVEC00	Suspension Cable, White Nylon 1/8" Diamond-Braid	1,000 ft/roll
CVEC10	Suspension Cable, Yellow Nylon 3/16" Std. Braid	1,000 ft/roll
CVEC20	Suspension Cable, Nylon, #15	350 ft/roll
CVED00	Hand Pump for Pressurized Bailer	Each



Global Water
The Leader in Water Instrumentation

In the U.S. call toll free
at 1-800-876-1172
International: 916-638-3429
Fax: 916-638-3270
Email: globalw@globalw.com

Visit our online catalog at:
www.globalw.com
Our Address:
11390 Amalgam Way
Gold River, CA 95670